

US100 Installation Guide

Hand-free Stand



Overview


Thank you for purchasing Cino US100 Hand-free Stand. The US100 is specifically designed for hands-free applications, delivering great flexibility to maximize users' comfort and productivity. This document provides an easy reference for assembling and installing the US100.



- Bracket
- 2 Scanner Holder
- Angle Adjustment Knob
- 4 Base
- Optional Part

Assemble the Stand

Step 1





Turn the base upside-down and open the base supporters.

2 Turn the base to the front side and place the base on your desired location.


If you would like to fix the stand by screw, please follow below procedures.

- Insert a M4 (approx. 8~10mm long) flat head self-tapping screw into the screw hole of the base.
- 2 Tighten the screw to secure the base to the flat surface.
- Please note that the M4 screw is not provided in this package.

Step 2



- Fit the bracket into the base to lock the bracket to the base.
- Place the scanner holder on the bracket groove properly.



- Insert the angle adjustment knob. Turn the knob clockwise to secure the scanner holder to the bracket.
- 2 The stand is now ready to be used with the scanner. You can loose the knob to adjust the angle.

Step 4



- Place the optional part onto the scanner holder.
- Secure the optional part on the scanner holder.
- The optional part is needed if you want to use the smart stand with F500 or L500 series scanner. If you do not use F500 or L500 series scanner, please skip this step.



Once you finished the stand installation, you can start using the scanner with the stand.

Dismount the Stand



- Take off the optional part and release the knob to remove the scanner holder.
- Prepare a long screwdriver and insert it into the hole on the top of the bracket.
- 3 Loose the screw from the base and remove the base from the mounted surface.



US100 Installation Guide International Edition, Rev. A2

P/N: YMAUF00010020R0

CINO GROUP

PC WORTH INT'L CO., LTD.

© Copyright PC Worth Int'l Co., Ltd. © Copyright Cino Group

